



ATESS NOVO EVA-11/22S-S/P

3-phase AC charger Quick installation guide

Disclaimer

This user manual is copyrighted by Shenzhen ATESS Power Technology Co.,Ltd.(Hereinafter referred to as"ATESS") No company or person may extract or copy part or all of this user manual without the written permission of ATESS. Content must not be transmitted in any form, including materials and publications.

All rights reserved.

ATESS has the final right to interpret this user manual. The information in this manual is subject to change without notice.

Thank you for using ATESS EVA charging equipment!

EVA series intelligent three-phase AC charger is a power supply device that uses professional and advanced technology to provide energy supply to electric vehicles, it also has friendly man-machine interface and versatile functions of control, billing, and communication. The charger can be connected to a back-office server to realize the functions of reservation and payment via Mobile phone APP. Diversified communication options, including wired Ethernet, WIFI, 4G is available for back-office server connection.









Menu

I. Product description	1
II. Packaging list	3
III. Installation and wiring	4
IV. Parameter setting	8
V. Operation instruction and LCD description	20
VI. Firmware update	24
VII. Troubleshooting	28
VIII. Use excess solar power to charge your car	36
IX. Load balancing	39
X. Specification	42
XI. Application	43
XII. Warranty	57
XI. Annex III	58


Safety precautions

This document contains important safety information about your AC charger. Please keep this file for future reference.

Please read this document thoroughly before installing and using the ATESS AC charger. Failure to follow safety instructions may result in electric shock, fire, serious injury or death.


	Check the charger cable and case regularly for damage. If the product is defective or damaged, suspend use and contact ATESS for advice.
	Do not open, repair, tamper or modify the charger in any way without authorization.
	We recommend that the charger installation, inspection, etc. be carried out by qualified electricians who have obtained relevant certificates, and the installation should comply with local wiring regulations to ensure safe use.
	Ensure that the charger is in the working temperature. Do not touch the surface of the charger in high temperature environment to avoid burns.
	Do not expose any part of the equipment or cable to strong force, impact, or sharp objects.
	There may be power left within 5 minutes after the charger is powered off. Please ensure that it is completely disconnected before operating.
	You can clean the surface of the charger with a soft, damp cloth without using solvents or abrasives. Power must be off before cleaning.
	This symbol on products and accompanying items indicates that used electrical appliances and other products should not be mixed with general domestic waste. For proper handling, recovery and recycling, please take this product to the designated collection point for disposal.

I. Product description



- 1.LOGO and status indicator
- 2.LCD display
- 3.RFID ready
- 4.Start or stop button
- 5.Socket outlet(plug holder for cabled version)
- 6.Mounting bracket
- 7.Side window and nameplate
- 8.Waterproof cable gland for AC input cables
- 9.Waterproof cable gland for communication wires

Wiring definition in the side window



1. Terminal block for CT/meter wiring. The terminal definition is:
 485A/485B is RS485 terminal for meter connection;
 Ia+/Ia- , Ib+/Ib-, Ic+/Ic- is for CT connection
 2. AC input terminals. Terminal definition is:
 L1/L2/L3/N/PE


II. Packaging list

No.	Name	Qty	Remark
1	Charger	1	
2	User manual	1	
3	Quality certificate	1	
4	Mounting bracket	1	
5	Cable hook	1	For cabled version
6	ST6.3X40 Stainless steel hex-head self-drilling screws	4-7	4 for socket version, 7 for cabled version(3 of the 7 screws is for cable hook fixing)
7	12X46 Plastic expansion plugs	4-7	4 for socket version, 7 for cabled version(3 of the 7 plugs is for cable hook fixing)
8	User card	1	RFID function will be equipped with user card


III. Installation and wiring

3.1 Mount on a wall


3.1.1 Open the packaging, you'll see a charge point, a mounting bracket, a user manual and a bag of mounting accessories. There is also an RFID card if the charge point is RFID version. For cabled version, a cable hooker is also included inside.





3.1.2 Remove the mounting bracket from the charge point, use it as a template to mark the position of the drill holes. Drill the holes and hammer the expansion bolts in the accessories bag into the holes. Then fix the mounting bracket onto the wall.



3.1.3 Put the charge point onto the bracket, and fix it with the 2 screws at the bottom of the charge point. The installation is done.




3.1.4 Crimp the below shown insulated ferrule or ring terminals on the end of the AC input wires. Connect the wires into the terminal block of the charge point as below. Close the side window with the cover, then the wiring is done.




	Model	L	N	PE
Terminal	11k			
	22k			
Wire	11k	≥2.5mm ² ≥AWG12	≥2.5mm ² ≥AWG12	≥2.5mm ² ≥AWG12
	22k	≥6mm ² ≥AWG9	≥6mm ² ≥AWG9	≥6mm ² ≥AWG9

3.2 Mount on a pole


3.2.1 Open the packaging of the pole, take out the pole and mounting accessories.



3.2.2 The pole must be installed on a hard surface, concrete surface is recommended, it can also be mounted on a solid ground. Drill holes according to the requirements marked on the illustration for fixing expansion bolts.




3.2.3 Fix the pole onto the holes with expansion bolts. The input cables shall go into the pole from the bottom middle area and come out of it from the area below the cable hooker.





3.2.4 Fix the mounting bracket onto the pole.

3.2.5 Position the charge point onto the bracket and secure it on the bracket with the 2 screws.



3.2.6 Crimp the below shown insulated ferrule or ring terminals on the end of the AC input wires. Connect the wires into the terminal block of the charge point as below. Close the side window with the cover, then the wiring is done.



	Model	L	N	PE
Terminal	11k			
	22k			
Wire	11k	≥2.5mm ² ≥AWG12	≥2.5mm ² ≥AWG12	≥2.5mm ² ≥AWG12
	22k	≥6mm ² ≥AWG9	≥6mm ² ≥AWG9	≥6mm ² ≥AWG9

Note:

1. Only professional personnel can do the wiring, connect the AC input wires in correct phase order according to the markings on the terminal block;
2. The PE terminal shall be connected to the Earth firmly and reliably
3. We recommend installing at least Type A 30mA of circuit breakers upstream of the charger;
4. No live work! Turn off the upstream breaker in the distribution panel and the breaker inside the charging equipment before repairing or maintaining.
5. Please do not disassemble the unit unless authorized!

IV. Parameter setting


After the charger installation and wiring, connect the charger and PC via network cable for parameter setting. For specific actions, please refer to the following details.

4.1 Set the IP address of the PC


The Charger's default IP address is 192.168.1.5. To access the parameter setting interface, you need to first set the computer's IP to 192.168.1.x (x can be any value between 1 and 255 except for 5, e.g. 192.168.1.10).

To set a static IP on your computer:


1. Click Start Menu > Control Panel > Network and Sharing Center. (For Windows 8 and higher, search for and open Control Panel and select Network and Internet).
2. Click Change adapter settings.




3. Right-click on Local Area Connection and click on Properties.



4. Select Internet Protocol Version 4 (TCP/IPv4) and click on Properties.




5. Select "Use the following IP address" and enter the IP address, Subnet Mask, Default Gateway. Click OK and close the Local Area Connection properties window.



4.2 Configure parameters

Connect the charger to a computer via a network cable. Open the web browser and type in <http://192.168.1.5:8080/> in the address field and click enter, then the parameter setting page of the charger will open up.

Parameter setting can only be done via web browser on a computer. It is suggested to use IE or Firefox, other browser might have compatibility problem.



Overview of Parameter setting page

Explanation of parameters:

(1) Firmware version of the Charger. This item cannot be modified here on the setting page.



Fig. 1

(2) Charger ID, this is the unique identification of the Charger. If the charger is to be connected to ATESS back-office server, this ID must be set as the serial number on the nameplate of the Charger. Otherwise the Charger cannot be registered on the server.



Fig. 2

(3) Charger IP. The default IP is 192.168.1.5. It is not suggested to change the default IP. If you have changed the default IP and forgot the new IP, you can reset the charger to factory setting by long press the reset button (the reset button on control board, not the red emergency stop button) until the charger reboot. Then you can use the default 192.168.1.5 for access.

Please note: After restoring the charger to factory setting, you'll need to reset the charger ID (same as serial number, can be found on the nameplate sticker) and server url, otherwise the charger won't be connected to the back-office server.




Fig. 3

(4) Charger Subnet mask. The default value is 255.255.255.0. It is not suggested to change. If the subnet mask has been reset to other value and you have forgotten the new value, you can restore the charger to factory setting by long press the reset button.

The screenshot shows two input fields. The first is labeled "DHCP Enable(0:STATIC,1:DHCP):" and contains the value "0". The second is labeled "Subnet Mask:" and contains the value "255.255.255.0".

Fig.4

(5) MAC address. This is the MAC address used for LAN cable connection. If the charger is connected to ATESS back-office server via LAN cable and the router has MAC access control, then you can put this MAC in the router to allow the charger to access server

The screenshot shows a single input field labeled "Net MAC Address:" containing the value "50:88:AA:60:95:5C".

Fig.5

(6) Enable the DHCP mode to automatically assign IP addresses to routers and Connect to charger via network cable under internet connection.

The screenshot shows a single input field labeled "DHCP Enable(0:STATIC,1:DHCP):" containing the value "0".

Fig.6

(7)The secret key to connect to the OCPP server for authentication.

The screenshot shows a single input field labeled "Authentication Key For OCPP:" containing the value "12345678".

Fig.7

(8) WiFi SSID(wireless network name) and WiFi Key(WiFi password) is used for WiFi connection

The screenshot shows two input fields. The first is labeled "WIFI SSID(MaxLen 30,Not support ',');" and contains the value "WIFI_Default". The second is labeled "WIFI Key(MaxLen 64,Not support ',');" and contains a series of asterisks "*****".

Fig.8

(9)Server URL is to set the domain name or IP address of the back office server to be connected.

The domain name of ATESS server is "ws://enerace-ws.atesspower.com/ocpp/ws";
IP address is "ws://47.56.208.172:80/ocpp/ws".

Heartbeat Interval is used for testing. No need change.

The screenshot shows two input fields. The first is labeled "Server URL(MaxLen 250):" and contains the value "ws://enerace-ws.atesspower.com/ocpp/ws". The second is labeled "Heartbeat Interval(0~3600 Sec):" and contains the value "60".

Fig.9

(10) Time of the charger. Set according to the local time. After the charger is connected to back-office server, the time will be synchronized with the server's time. If the charger has no server connection, then you'll have to reset the time every time you turn off and back on the charger.

The screenshot shows two input fields. The first is labeled "Charger Time(YY-MM-DD HH:MM:SS):" and contains the value "2020-01-01 02:30:56". The second is labeled "Time Zone:" and contains the value "UTC+00:00".

Fig.10

(11) Login password is used for web page login parameter settings, the default password is 1234578.

Login Password:	<input type="password" value="*****"/>
-----------------	--

Fig.11

(12) Over temperature protection value, not suggested to change.

Max Temperature(Max 85):	<input type="text" value="80"/>
--------------------------	---------------------------------

Fig.12

(13) Interval for uploading metering data during charging, keep the default value.

MeterValue Interval(0~300 Sec):	<input type="text" value="60"/>
---------------------------------	---------------------------------

Fig.13

(14) 4G connection, when the 4G network cannot be connected, login SIM card APN and other information

4G Account(Maxlen 30):	<input type="text"/>
4G APN:	<input type="text" value="Default"/>
4G Password(Maxlen 30):	<input type="text"/>

Fig.14

(15) DC residual current sampling value calibration. Enter 0 and press "Set and Reboot" to calibrate the DC RCD ring. Display real-time detection value of DC residual current. keep the default RCD level.

TypeB RCD1(Enter 0 Calibration):	<input type="text" value="0.70"/>
Type B RCD Protection Level:	<input type="text" value="3"/>

Fig.15

(16) For the charger with an integrated meter, set the meter model and address and keep the default value.

Measure PowerMeter Type:	<input type="text" value="Eastron SDM720 MID"/>
Measure PowerMeter Addr:	<input type="text" value="1"/>

Fig.16

(17) Set low electricity prices for charging time to reduce costs.

Off Peak Charge(0:Disable,1:Enable):	<input type="text" value="0"/>
Off Peak Time1(HH:MM-HH:MM):	<input type="text" value="11:00-16:00"/>
Off Peak Time2:	<input type="text" value="22:00-08:00"/>
Off Peak Time3:	<input type="text" value="00:00-00:00"/>
Off Peak Time4:	<input type="text" value="00:00-00:00"/>
Off Peak Time5:	<input type="text" value="00:00-00:00"/>
Off Peak Current1(A):	<input type="text" value="32"/>
Off Peak Current2:	<input type="text" value="32"/>
Off Peak Current3:	<input type="text" value="0"/>
Off Peak Current4:	<input type="text" value="0"/>
Off Peak Current5:	<input type="text" value="0"/>

Fig.17

(18) Relieve the power grid pressure, authorized charging, after the set time to start.

Rand Delay Charge Time(Sec):

Fig.18

(19) Open the function, the user's home meter provides dry contact signal, identify the off-peak period, reduce the charge of electricity

Grid Off Peak Charge(Plug&Charge, 0:Disable 1:Enable):

Fig.19

(20) Loadbalancing, sets the total power input of the home grid to avoid tripping.

Power Distribution Charge(0:Disable,1:Enable)
External Maxlimit Power:

Fig.20

(21) To set the working mode of solar, the ECO mode requires setting the KWH of electricity obtained from the grid.

Solar Mode Charge(0:Disable,1:ECO,2:ECO+):
Grid Limit Charging Current(Solar Mode: 6-63A):

Fig.21

(22)Set the load balancing or Solar function, sampling instrument type and address.

External Power Smpling
Wiring(0:CT2000:1 1:PowerMeter 2:CT3000:1): _____
LoadBalance PowerMeter Type:
LoadBalance PowerMeter Addr:

Fig.22

(23) Set the display language of the charger LCD.

Language Set:

Fig.23

(24) The charger model, can not be modified, factory default.

Machine Type:

Fig.24

(25) Set the output current of the charger to limit the output power of the charger.

Max Output Current Set(6~63A):

Fig.25

(26) Charging mode setting. 1: APP/RFID mode; 2: RFID mode; 3: Plug&Charge mode.

Charge Mode(Default 1:APP,2:RFID,3:Plug&Charge):

Fig.26


(27) PIN of the charger, used to verify the PIN of user card. To use a RFID card with the charger, their PIN must be consistent. If the user card has a different PIN, then it cannot be used on this charger. The default PIN setting of the charger is 242007.



Card Pin(6 digits, E.g:123456):

Fig.27

(28) Set the tariff for charging energy.



Charging Rate (Per KWh):

Fig.28

(29) Set daylight saving time for the charger to switch automatically.



Daylight Saving Time(MM-DD):

Fig.29


(30) The time for automatic charging in Plug and charge mode.



Auto Charging Time(Plug&Charge):

Fig.30

(31) In any mode, after the authorized charger starts, wait for the time to connect the electric vehicle.



Wait For Plug Gun Time(Sec):

Fig.31

(32) The communication interval between the charger and server,keep the default value.



Heartbeat Interval(0~3600 Sec):

Fig.32

(33) After modifying any parameters, click "Set and Reboot" to take effect. Some parameters may cause the charger to automatically restart.



Set and Reboot

Fig.33


(34) Upgrade the firmware of the charger. After clicking upload, the charger will restart.



Firmware Updating
选择文件 未选择任何文件 Upload

Fig.34

(35) Restore the charger to factory Settings.



Restore factory settings
Reset

Fig.35

V. Operation instruction and LCD description

5.1 Charging mode and Operation


APP mode:

Initiate or cease charging by scanning QR code using APP . You can also use APP for reservation and payment provided that the back-office server supports such functions.




APP mode operation process flow

If you are using the ATESS APP, Charging can be started/stopped by pressing the " / " button on the APP.



RFID mode:


Charging can only be initiated or ceased by swiping RFID card.



RFID mode operation process flow





Plug&Charge:



Charging will start automatically after EV plugged in. If you want to stop the charging, just press the forced on/off button on the side of the charger.



Plug&Charge mode operation process flow

5.2 LCD interface introduction

 <p>2021-07-21 17:59:11 EV charger</p> <p>Please swipe your card or scan the code first</p> <p>RFID Card QR Code</p> <p>Connected Mode: Plug&Charge EVA-22S-SE-V5.2.4-20230307-NOVO</p>	<p>Interface of standby status. Charging mode is displayed at the bottom centre of the screen.</p>												
 <p>2021-07-21 17:59:11 User information</p> <p>Please connect the vehicle with plug</p> <p>ID 111 024 785 465 142 6 Balance 56.12</p> <p>Connected Mode: Plug&Charge EVA-22S-SE-V5.2.4-20230307-NOVO</p>	<p>Interface of user card information Displayed for user to check card ID and balance when swiping RFID card while EV is not connected</p>												
 <p>2021-07-21 17:59:11 Charging interface</p> <p>Power (kWh) 254.21 Time 11:21:50</p> <table border="1"> <thead> <tr> <th></th> <th>Voltage(V)</th> <th>Current(A)</th> </tr> </thead> <tbody> <tr> <td>L1</td> <td>235.20</td> <td>32.00</td> </tr> <tr> <td>L2</td> <td>235.20</td> <td>32.00</td> </tr> <tr> <td>L3</td> <td>235.20</td> <td>32.00</td> </tr> </tbody> </table> <p>Connected Mode: Plug&Charge EVA-22S-SE-V5.2.4-20230307-NOVO</p>		Voltage(V)	Current(A)	L1	235.20	32.00	L2	235.20	32.00	L3	235.20	32.00	<p>Interface of charging status. Displayed when the charging is being carried out. There is charging time, consumed electricity, charging cost on it, as well as real-time charging voltage and charging current.</p>
	Voltage(V)	Current(A)											
L1	235.20	32.00											
L2	235.20	32.00											
L3	235.20	32.00											
 <p>2021-07-21 17:59:11 Charging complete</p> <p>Time duration 11:21:50 Power (kWh) 254.21</p> <p>ID BVE0A01002 Batch 202403040007</p> <p>Please pull out the charging gun Put it into the charging pile</p> <p>Thank you for your cooperation</p> <p>Connected Mode: Plug&Charge EVA-22S-SE-V5.2.4-20230307-NOVO</p>	<p>Interface of charging complete. Displayed when the EV stops charging, or forced on/off button is pressed on charger side.</p>												

 <p>2021-07-21 17:59:11 Fault interface</p> <p>Fault Code 100</p> <p>Emergency stop press or emergency stop is broken</p> <p>Connected Mode: Plug&Charge EVA-22S-SE-V5.2.4-20230307-NOVO</p>	<p>Interface of fault status. Displayed with fault code and fault description when fault occurs.</p>
 <p>2021-07-21 17:59:11 Reservation interface</p> <p>Remaining time 11:21:50 ID 202403040007</p> <p>Connected Mode: Plug&Charge EVA-22S-SE-V5.2.4-20230307-NOVO</p>	<p>Interface of reserved status. If the back-office server and APP support reservation function and the charger is reserved, this interface will come out showing user ID and remaining time to reserved time.</p>

VI. Firmware update


6.1 Update by SD card

There are 2 ways to update firmware for EV charger

1. Update by SD card
2. Update on parameter setting page

The firmware file must be named as "App.bin".


1. Prepare a microSD card with capacity not greater than 4G. Format the SD card using FAT32.




2. In the root directory of the SD card, rename the firmware file as "App.bin". And create a txt file with name of "UploadConfig.txt".

	App.bin	2018/12/5 15:58	BIN 文件	168 KB
	UploadConfig.txt	2018/12/6 15:04	文本文档	0 KB

3. Open the txt file, write "state=1" in it and save the file.



4. Insert the SD card into the charger, turn off and back on the charger, the update will start automatically. The indicator will first flash red and then flash green with a long beep as the end of the update(sometimes the beep sound may not be clearly heard). After the update is done, turn off the charger and remove the SD card.



Micro SD slot of 11/22kW charger

5. Check the current firmware version on LCD or the parameter setting page.

To check firmware version on the parameter setting page

Connect the charger to computer via a network cable, the computer's IP must be within the 192.168.1.x segment(x is any value between 1 and 255 except 5).Open the web browser, type in the charger's default IP of "http://192.168.1.5:8080" and click enter, then you can check the firmware version on the appeared parameter setting page.

Configure Charger Parameters

Firmware Version Num:	EVA-22S-SE-V5.2.4.20230307.NOV0	Language Set:	English
Charge ID(MaxLen 20):	SLD00208SE	Machine Type:	EVA-22S-SE
Charger IP:	192.168.1.5	Default Gateway:	192.168.1.1
Subnet Mask:	255.255.255.0	Charger DNS:	8.8.8.8
Net MAC Address:	50:88:A9:AC:41:58	Max Output Current Set(6~63A):	32.0
DHCP Enable(0:STATIC,1:DHCP):	0	Charge Mode(Default 1:APP,2:RFID,3:Plug&Charge):	3
Authentication Key For OCPP:	12345678	Card Pin(6 digits, E.g:123456):	242007
WIFI SSID(MaxLen 30,Not support ','): AX3000		WIFI Key(MaxLen 64,Not support ','): *****	
Server URL(MaxLen 250): ws://emance-ws.atepower.com/ocpp/ws		Charging Rate (Per KWh):	1.0
Charger Time(YY-MM-DD HH:MM:SS): 2023-04-17 10:29:32		Time Zone:	UTC+00:00
Login Password: *****		Daylight Saving Time(MM-DD):	00-00&00.00
Max Temperature(Max 85): 80		Auto Charging Time(Plug&Charge):	00:00:00.00
MeterValue Interval(0~300 Sec): 60		Hearbeat Interval(0~3600 Sec):	60
4G Account(Maxlen 30):		4G Password(Maxlen 30):	
4G APN: Default		Wait For Plug Gun Time(Sec):	90

6.2 Update on parameter setting page

Using this method for update doesn't require any specific name for the firmware file.

1. Connect the charger to a computer with IP address set as 192.168.1.x(x can be any value between 1 and 255 except 5) via a network cable. Open web browser and type in the charger's default IP address—http://192.168.1.5:8080, click enter then you'll get into the parameter setting page.

2. Scroll down to the below field.

Firmware Updating

D:\Desktop\App.bin

3. Click the "Browse" button and select the firmware file. Click "Upload", then update will start automatically.

During the update, the LED indicator will behave as below,

First flash red and goes out with a short beep sound, during this period the firmware file is transmitted to the charger's flash memory from the computer;

Then flash red again for some seconds and quickly change to green light flashing. During this period, the charger is updating the firmware to its micro controller.

When the green light goes out, there will be a long beep sound. That means the firmware is successfully updated.

The beep sound may not be audible with the front cover fixed on the charger.

If the update doesn't start after click "Upload", Turn off and back on the charge to try again.

4. You might see below content. If the charger is already successfully reboot after the firmware update, close the browser and open it again to set the current firmware version.

VII. Troubleshooting

7.1 Troubleshoot by LED behavior or LCD display

If fault occurs, users can check the fault information on the LCD or by the number of blinks of the LED indicator light. Each fault is indicated with a sequence of different numbers of LCD blinking. A pause of 3 seconds between each sequence indicates the beginning or end of a sequence. If multiple faults happen at the same time, each sequence of blinking shows in chronological order at an interval of 3 seconds.

Please see the table below for detail information

No.	Fault code on LCD (if available)	Number of blinks of the LED	Fault description
1	100	3	The silver emergency stop button is pressed or broken
2	101	1	Over voltage on phase L3
3	102	2	Under voltage on phase L3
4	103	1	Over voltage on phase L2
5	104	2	Under voltage on phase L2
6	105	1	Over voltage on phase L1
7	106	2	Under voltage on phase L1
8	107	2	Three phase are undervoltage
9	108	4	Over current
10	109	5	Over temperature
11	110	6	leakage current fault
12	111	7	Rs485 communication fault
13	112	8	Reserved
14	113	9	Reserved
15	114	10	Relay fault
16	115	11	PE fault
17	116	12	Reserved
18	117	13	Out of service
19	118	14	Door opened

7.2 Firmware update fails


7.2.1 Firmware update failure with SD card:

- Check if the capacity is over 4G bytes, please use a SD card of less than 4G to retry;
- Check if the SD card is formatted with FAT32;
- Check if the firmware file is renamed as App.bin;
- Check if you have filled in "state=1" in the UploadConfig.txt file.

7.2.2 Firmware update failure with laptop:

Please try with IE browser. Or reboot the laptop to retry.

7.3 WiFi connection&APP issue



- Check WiFi signal strength;

Signal strength on PC:



Signal strength on mobile:



b. Please check and input the correct WiFi SSID and password to retry;

Configure Charger Parameters

Firmware Version Num: EVA-22S-SE-V5.2.4.20230307.NOVVO Language Set: English

Charge ID(MaxLen 20): SLD00208SE Machine Type: EVA-22S-SE

Charger IP: 192.168.1.5 Default Gateway: 192.168.1.1

Subnet Mask: 255.255.255.0 Charger DNS: 8.8.8.8

Net MAC Address: 50.88.AB.AC.41.58 Max Output Current Set(6~63A): 32.0

DHCP Enable(0:STATIC,1:DHCP): 0 Charge Mode(Default 1:APP,2:RFID,3:Plug&Charge): 3

Card Pin(6 digits, E.g.:123456): 242007

Authentication Key For OCPP: 12345678

WiFi SSID(MaxLen 30,Not support ','): AX3000 WiFi Key(MaxLen 64,Not support ','): *****

Server URL(MaxLen 250): ws://emerce-ws.aliexpress.com/ocpp/ws

Charger Time(YY-MM-DD HH:MM:SS): 2023-04-17 10:29:32

Charging Rate (Per kWh): 1.0

Charger Time(YY-MM-DD HH:MM:SS): 2023-04-17 10:29:32

Time Zone: UTC+00:00

Login Password: *****

Daylight Saving Time(MM-DD): 00-0000-00

Max Temperature(Max 85): 80

Auto Charging Time(Plug&Charge): 00:00:00:00

Meter/Value Interval(0~300 Sec): 60

Hearbeat Interval(0~3600 Sec): 60


4G Account(MaxLen 30):

4G Password(MaxLen 30):

4G APN: Default

Wait For Plug Gun Time(Sec): 90


If you check the WiFi setting on the APP, please turn off and back on the charger and connect your mobile to the WiFi emitted by the charger for checking and setting.



c. Check if there is access control in the router, e.g. MAC filtering, port blocking, etc.

To verify this, you can use your mobile phone to create a hotspot and try to connect the charger to this mobile hotspot. If charger can connect to the hotspot, but cannot connect to the router, there must be access control in the router, please check with the site owner for this.

Check if charger is connected on Device list of the hotspot setting page



d. 1. Some routers have 2 WiFi, one is 2.4GHz, the other is 5GHz. Most homes just use the 5GHz WiFi as their default WiFi. But the charger can only connect to the 2.4GHz WiFi. So if the charger can connect to your mobile phone hotspot, but cannot connect to the home WiFi. Please check with the home owner or check on their router to see if you are using the 5GHz WiFi. Please do use the 2.4GHz WiFi for charger connection.


2. When the WiFi signal strength is lower than -75dbm, the charging point will not be able to connect with WiFi.

(1) Download the WiFi signal strength test tool from the app store to check whether the WiFi signal strength connected to the charging point is greater than -75dbm.

(2) If the WiFi signal strength is weak, it is recommended to use AP repeater to increase the signal strength, which can enlarge the WiFi signal range.

Wireless	Enabled
Wireless Network Name (SSID)	SKYE2496 (2.4 GHz), SKYE9689 (5 GHz)
Wireless Network Visible	Yes
Current Wireless Channel	13 (2.4 GHz), 36 (5 GHz)
Wireless Encryption	WPA2-PSK


Devices connected to your home network	
Device Name	MAC Address
UNKNOWN	70:70:0d:d5:bce:5
iPhone	88:e8:7f:9e:2f:ac
Z3C01K568FLDUZ	20:47:47:3d:85:f4
HUAWEI_nova_2s	ec:89:14:40:3b:9c
8ed02a6f95	
iPhone	a8:5c:2c:30:d7:07
Phiyee-iPad	78:7e:61:c3:f7:03
LATTITUDE-05	34:e1:2d:b5:c7:fa
Phiyee-iPhone	b8:53:ac:4d:05:50
UNKNOWN	40:99:22:2a:fc:93
UNKNOWN	00:1b:67:16:d7:82



e. Check if the charger is still connected to the computer. Please unplug it from computer otherwise the charger won't connect to the back-office server.

f. Check if server address is correct in the "Server URL" field. The correct setting is :

ws://enerace-ws.atesspower.com/ocpp/ws



7.4 Cannot access parameter setting page


a. Check if you have connected the charger to your computer,

b. Check if you have change the computer's IP to 192.168.1.x(x can be any value between 1 and 255 except 5).


To set a static IP on your Windows computer:

(1). Click Start Menu>Control Panel>Network and Sharing Center. (For Windows 8 and higher, search for and open Control Panel and select Network and Internet).


(2). Click Change adapter settings.




(3). Right-click on Local Area Connection and click on Properties.




(4). Select Internet Protocol Version 4 (TCP/IPv4) and click on Properties.



(5). Select "Use the following IP address" and enter the IP address, Subnet Mask, Default Gateway. Click OK and close the Local Area Connection properties window.



- c. Check what web browser is being used, it's suggested to use Firefox or IE, Chrome cannot be used to update firmware.
- d. Check if you have input the complete content, which is `http://192.168.1.5:8080`, in the address field, do not leave out the `http://` or the `:8080`.
- e. Sometimes you may need to restart the charger to access its parameter setting page.
- f. If you have changed the charger's IP to other value and cannot remember, you can restore the charger to factory setting by long press the reset button. Then you can access it using `http://192.168.1.5:8080`



Please note: After restoring the charger to factory setting, you'll need to reset the charger ID and server url, otherwise the charger won't be connected to the back-office server.

7.5 Charging issue


If charging cannot start after the car is plugged in,

- a. Check if the red emergency stop button is pressed.
- b. Check what charge mode is being used

APP: Charge can only be started/stopped by APP or RFID card, and the charger must be connected to the back office server already;


RFID: Charge can only be started/stopped by RFID card;

Plug and charge: Charge will start automatically when car is plugged in.



- c. Check if off-peak charging is set and if charger's time is correct.

If off-peak charging is set, charge can only start within the charging allowed time period.



VIII. Use excess solar power to charge your car

The charge point can work with grid-tied solar system, to detect and use the residual solar power to charge your car that otherwise would be fed back to grid. This can help increase the self-usage rate of the solar system and reduce electricity bill for the household.

The charge point supports 3 charge modes with grid-tied PV system: FAST, ECO and ECO+.

8.1 Introduction to the 3 modes for solar charge

FAST mode: Charge at the rated power, the car can be fully charged in the shortest time at this mode.

ECO mode:

(1) solar function set the power p range : P_e stands for rated power, P_1 stands for Power

Transferred to Power Grid by Photovoltaic.

1. The power of three-phase charger belongs to $(5.3kW - P_e)$

(2) The condition of changing duty cycle of charger : P_2

1. The power of three-phase charger $P_2 = 1000W$

(3) Operation mode :

1. when Initial charging, Permissible output power of charger $p_3 (P_3 = P)$

2. If $P_1 < P_2$, Permissible output power of charger $P_3 (P_e \geq P_3 \geq P)$

3. If $P_1 \geq P_2$, Charger will Increase Permissible Output Power, When detected during this process $P_1 < P_2$ or $P_3 = P_e$. Charger will stop increasing allowable output power, now the allowable output power of charger $P_3 (P_e \geq P_3 \geq P)$


ECO+ Mode:

In this mode, the charging point only uses the electricity sent by the photovoltaic inverter to charge the electric vehicle. When the current sent by the inverter is less than 6A, the charging point will stop charging. Please choose this mode carefully.


8.2 Wiring

To monitor the real-time power import and export, a CT or meter is needed for this function to work properly.

If CT is used, the wiring will be as below.



8.3 If meter is used, please wire it as below



8.4 Parameter configuration for this function

- (1) Connect the charge point to a laptop with a network cable, access the parameter setting page on the web browser of the laptop.
- (2) Scroll down to find the following parameters: Solar Mode, FAST, ECO or ECO+.

Solar Mode Charge(0:Disable,1:ECO,2:ECO+):	<input type="text" value="0"/>
Power Distribution Charge(0:Disable,1:Enable)	<input type="text" value="0"/>

- (3) Select CT or meter as sampling device of this solar charge function. Scroll down to find the option: External Power Sampling Wiring(0:Inner CT 1:PowerMeter). If CT is used, please set it to 0; if meter will be used, please set it to 1.

External Power Smplng Wiring (0:Inner CT 1:PowerMeter):	<input type="text" value="0"/>
Peak Valley Charge (0:Disable 1:Enable):	<input type="text" value="0"/>

- (4) If you choose the PowerMeter.Plesae choose PowerMeter Type, change PowerMeter Addr to the address shown on the meter.

External Maxlimit Power:	<input type="text" value="45"/>	2:CT3000(1): Grid Off Peak Charge(Plug&Charge, 0:Disable 1:Enable):	<input type="text" value="0"/>
LoadBalance PowerMeter Type:	Easton SDM230	LoadBalance PowerMeter Addr:	<input type="text" value="22"/>
Measure PowerMeter Type:	Null	Measure PowerMeter Addr:	<input type="text" value="1"/>
Off Peak Charge(0:Disable,1:Enable):	Easton SDM230	Off Peak Current1(A):	<input type="text" value="20"/>
Off Peak Time1(HH:MM-HH:MM):	18:00-19:00	Off Peak Current2:	<input type="text" value="15"/>
Off Peak Time2:	20:00-22:00	Off Peak Current3:	<input type="text" value="25"/>
Off Peak Time3:	23:00-23:13	Off Peak Current4:	<input type="text" value="23"/>
Off Peak Time4:		Off Peak Current5:	<input type="text" value="22"/>
Off Peak Time5:			
Rand Delay Charge Time(Sec):	<input type="text" value="0"/>		

[Set and Reboot](#)


[Firmware Updating](#)

IX. Load balancing


Introduction

The charge point can monitor the total power consumption of the household during charging. If the power consumption approaches the preset max value, the charge point will reduce charge power to avoid the situation of main breaker trip due to overload. It will adjust the charging power dynamically and in real-time thus the car can always be charged with the maximum allowable power.

9.1 Similar with the solar charge function, a CT or meter is needed to detect the power import. If a CT is used, please wire it as below,



9.2 If SDM630MCT meter is used, the wiring will be as the following



9.3 Parameter configuration for this function

- (1) Connect the charge point to a laptop with a network cable, access the parameter setting page on the web browser of the laptop.
- (2) Scroll down to find the following parameter: Power Distribution Enable(0:Disable, 1:Enable) and set it to 1 to activate the power modulation function.

Power Distribution
 Enable(0:Disable,1:Enable)

External Maxlimit Power(kW):

PowerMeter Addr:

- (3) Select power sampling device in the field of the parameter: External Power Sampling Wiring(0:Inner CT 1:PowerMeter). 0 means CT while 1 stands for meter.

External Power Smping Wiring(0:Inner CT 1:PowerMeter):

Peak Valley Charge(0:Disable 1:Enable):

- (4) Set the maximum power import value in the field of External Maxlimit Power(kW). To avoid nuisance tripping of the main breaker, it is suggested to set this parameter slightly lower than the max supply power of the property. e.g. the max supply power is 15kW, you can set the max power import to 13kW or 14kW.

Power Distribution
 Enable(0:Disable,1:Enable)

External Maxlimit Power(kW):

PowerMeter Addr:

- (5) If you choose the PowerMeter.Plesae chose PowerMeter Type, change PowerMeter Addr to the address shown on the meter.

External Maxlimit Power:	<input type="text" value="45"/>	2:CT3000:1:	<input type="text" value="0"/>
LoadBalance PowerMeter Type:	Easton SDM230	Grid Off Peak Charge(Plug&Charge, 0:Disable 1:Enable):	<input type="text" value="22"/>
Measure PowerMeter Type:	Null Acrel DDS1352 Acrel DTS1352(Three) Easton SDM230	LoadBalance PowerMeter Addr:	<input type="text" value="1"/>
Off Peak Charge(0:Disable, 1:Enable):	Easton SDM230	Measure PowerMeter Addr:	<input type="text" value="1"/>
Off Peak Time1(HH:MM-HH:MM):	Easton SDM300(Three) Easton SDM120 MID Easton SDM720 MID(Three) On-Rail DTSA666 MID(Three) Acrel AGF-AE SM-US-200	Off Peak Current1(A):	<input type="text" value="20"/>
Off Peak Time2:	18:00-19:00	Off Peak Current2:	<input type="text" value="15"/>
Off Peak Time3:		Off Peak Current3:	<input type="text" value="25"/>
Off Peak Time4:	20:00-22:00	Off Peak Current4:	<input type="text" value="23"/>
Off Peak Time5:	23:00-23:13	Off Peak Current5:	<input type="text" value="22"/>
Rand Delay Charge Time(Sec):	<input type="text" value="0"/>		

[Firmware Updating](#)

X. Specification

Model	NOVO EVA-11/22S-S/P
Dimension(mm)	246/382/162mm
Weight(kg)	<3.5/6.5
Display	LCD
Casing Material	Stainless steel& Engineering plastics& Tacyrylic
Input	
Voltage	AC 400V
Output	
Voltage	AC 400V
Max current	32A
IP Protection degree	IP65
Working environment temperature	-25°C~ +50°C
Relative humidity	5%~95%
Altitude	≤2000m
Frequency	50/60Hz
Communication	Ethernet/WIFI/4G
Charging mode	APP/RFID/Plug and charge
Standby power	<8W
Standard	IEC-62196-2;EN61851
Mounting	Pole/Wall
Certificate	CE/RCM
Protection features	
Overvoltage	450V
Undervoltage	329V
Overcurrent	18/35.2A
Leakage protection	DC 6mA+AC 30mA
Over temperature	Yes
Lightning protection	Type II

XI. Application

11.1. APP Introduction

11.1.1 Description

EneRace is an app for controlling charger. It can help you quickly and easily charge your vehicle with a EV charger.

11.1.2 Main Function Of **EneRace**

- (1) The APP can push the transfer information of the charger.
- (2) The user can control the start and stop of the charger through the APP.
- (3) The user can preset the charging scheme and scheduled charging.
- (4) The user can modify the parameter settings of the charger.
- (5) Users can authorize other users to use their own charger.
- (6) The user can view the charging record and report to email.
- (7) Users can manage and set up their own accounts.

11.1.3 Performance

APP has good ease of use and reliability, and guarantees the security and confidentiality of information.

11.2. Instructions

11.2.1 APP download and install

Users can install **EneRace** by scanning the below QR code or download it from the APP store(IOS) or GooglePlay(Andriod).




<IOS>



<Andriod>


11.2.2 Registration and login

When the user first visits, the user registration is performed by the following steps: Click the desktop icon Login page Register. When the user has an account, you can directly enter the user name and password to log in. If you forget the password, you can click the login page, forget the password button, and follow the prompts to retrieve the password through the mailbox.




11.2.3 Add Charger

IF you use ATS Charge for the first time, you need to add charger in the APP to facilitate setting and controlling the charger. The process of adding a charger is as follows: Click "Add" to add a charger by scanning the QR code (LCD/nameplate) or entering the charger ID. you can check the QR code/Bar code on the side window nameplate.




11.2.4 Charger switch and delete


When you have multiple chargers, you can switch chargers by clicking the arrow. A list of chargers can be found in the account information, swipe left to delete.



11.2.5 Start and stop control of charger




Press “  /  ”to turn on/off.

Note: when charger status is Preparing , you can press  to start charging.


11.2.6 Cable locked

For chargers in the socket version, the connector can be unlocked via this button after setting up the manual unlock function




11.2.7 Charging record

Press “Record” to view past charge records, including changer ID, gun number, time, energy, cost and so on. You can also view the energy consumption curve over time, and download the charging report to your email or local reference.



11.2.8 Preset charging scheme



There are three Pre-set charging schemes: Duration, Amount and Energy. Users can choose one of these options. The scheme can be canceled before the start charging time is reached. For example, in the "Amount" mode, you can set the amount and stop charging if the amount reaches the set value.


(1) Duration mode: Users can set the duration and start time of charging according to their consumption habits.

(2) Amount mode: Before setting this mode, you need to set the tariffs on the parameter


"charger settings" interface, enter the predetermined amount and start charging time, and stop charging when the set amount is reached.

(3) Energy mode: Set the energy ahead of time and the charger will stop charging after reaching the set energy.

Note: The function is always effective after "Everyday" is enabled.



11.2.9 Charger parameter settings Basic parameter Settings and function Settings of the charger, including Basic info, Charger settings, load balancing , authorization, off-peak Regulations, charging tariffs, connect to WIFI and Firmware upgrade.



Basic info


Charger ID: The authentication code of the charger cannot be modified;

Version : Firmware version of the charger;

Charger Name: A custom name for the charger;

Country: Set the current country so that the charger displays the correct time;

Time zone: Set the current time zone so that the charger displays the correct time.



Charger Settings

Charging mode : Three modes control the charging of the charger, APP, RFID and plug and charge.

Solar Mode: The Solar feature works in three ways, Fast, ECO and ECO+. In ECO mode, you need to set the power that can be allowed obtain from the grid.

ECO current limit : In solar mode, part of the charging energy comes from the photovoltaic and part from the grid. Here, set the power that is allowed to be obtained from the grid.

Electronic lock : Set the way to disconnect the connector after charging. You can unlock the connector manually or automatically through the APP.


Maximum output current: Limit the output capacity of the charger. For example, a 7kw charger with a maximum output of 32A can limit the output power by limiting the output current. Calculation mode:

single phase charger: $230V \times (XX)A = XX(KW)$, $230V \times 32A = 7.36KW$
Three phase charger: $230V \times (XX)A \times 3 = XX(KW)$, $230V \times 32A \times 3 = 22KW$

Low-power Reservation: After the EV is connected to the charger, and start a pre-set charging session, the charger will output Minimum power before reaching the pre-set time.

LCD close Enable: For the charger with LCD screen, you can control the LCD on or off.



Warm-up function: After the car starts preheating function, it will not consume the electric energy of the battery, which is provided by the charger.



Load balancing

Wiring sampling: The load balancing function and the solar function detect the type of tool for fuse or grid power. CT2000, CT3000 and meter.


Total domestic power(kw): Set the total capacity of the home grid to maintain a balance between load and charger to avoid overload trips. If your detection tool is a meter, you need to select the corresponding model and set the meter address(check on the meter screen).



Authrization



To manage authorized users, you can view the authorization time, account name, and delete user in the authorization management interface.

Users can authorize other users to use charging stubs through authorization management. Enter the user name to authorize other users to use the chargepoint. If the person you want to authorize does not have an account, you can register for the new user by registering the new user in the upper right corner.



Off-peak Regulations


According to the power price, set the output capacity of the charger in various time periods to save electricity costs. You can set a maximum of five time periods.



Charging tariffs

Currency: Select the currency in which the charge is settled and the charge report displays the bill with currency.





Tariffs setting: The charge tariff is used to calculate the cost of electricity consumed. The charge report shows the total cost. You can set up tariffs for up to 5 different time periods.



Connect to WIFI

When the charger is not connected to the server, every 60 seconds will switch to AP mode. search for the charger WIFI, and the WIFI name is the charger ID. After connecting the charger WIFI, you can enter the setting page to set the parameters of the charger. When the charger is connected to the network, you can switch to AP mode in the parameter setting, set the charger to AP mode, and then connect.

Switching to AP mode can switch the STA mode to AP mode. If it is not operated for 60s, it will switch back to STA mode and connect to the server. Click the "connect to WIFI" button to enter the hot spot connection page. When connecting WIFI at the charging point, please note the charger ID of the current stub. The connected hotspot must be the charger ID. Click the upper right corner of the hotspot connection page to view the operation instructions of the WIFI Direct connection function.




Only when the charger is in AP mode can you use the phone to connect to the charger.

The charger ID is displayed in AP mode and the charger parameters can be set. Pay attention to the format restrictions of the parameters when setting the pole parameters.

- (1) IP address, gateway, mask, and DNS should be filled in according to the four-segment number format, for example: 192.168.1.1
- (2) The following parameters must be integers: heartbeat interval (5-300), PING interval (5-300), meter upload interval (5-300), maximum output current of the pole (greater than 3), protection temperature (65 -85), externally monitors the maximum input power (greater than 3).
- (3) rate range is (0-5000), you can set the decimal.
- (4) The following parameters can only be numbers or letters: card reader key, WIFI password, Bluetooth password, 4G password, 4G APN, handshake login authorization key.
- (5) The following parameters can only enter numbers, uppercase and lowercase letters, icon page to view the operation instructions of the WiFi Direct connection function. underscores (_), spaces, bars (-): wifi name, Bluetooth name, 4G username.

Firmware upgrade

EV charger firmware upgrade, when there are new functions and other upgrades, users can achieve one-click upgrade through the interface.





11.2.10 Account Management

Users can manage their accounts, set their avatars, change their passwords, and bind their mobile phone numbers and mailboxes.

Change password: You need to verify the original password, then enter and confirm the new password.

Modify the phone number: Follow the steps to verify the new phone number with a verification code.

Modify the mailbox: Follow the steps to verify the new mailbox by verification code.



Warranty

The warranty period of this product (Including hardware and software) is 2 year. If the contract stipulates otherwise, the contract shall prevail.

For warranty cases during the warranty period, the customer should present the invoice of the purchase of the product to our service team. At the same time, the nameplate on the product should be clearly visible, otherwise the warranty claim might not be accepted.

Warranty condition

We will repair or replace the product free of charge during the warranty period. The defective machine after replacement shall be owned by us, and the customer shall reserve a certain amount of time for us to repair the faulty machine.

Liability exemption

We reserves the right not to accept the warranty claim if the conditions below happen;

- 1.No trademark on the product;
- 2.Warranty period has expired;
3. Fault or damage caused by incorrect installation, by installing the device in a not allowed environment, by improper storage or usage, etc.(e.g. too high or too low temperature, moisture or too dry environment, high altitude or unstable voltage/ current etc.
- 4.Failure or damage caused by the installation repair, modification or disassembly by unauthorized service personnel;
- 5.Failure or damage caused by using our non-genuine spare parts;
- 6.Damage or damage caused by accident or human cause (operational error, scratching, handling, bumping, access to inappropriate voltage, etc.), or transport damage;
- 7.Failure or damage caused by force majeure such as natural disasters (such as earthquakes, lightning strikes, fires, etc.)
- 8.Other failures or damages that are not caused by quality problem of the product or its components.

Statement of liability

The copyright of this manual belongs to our company. Any organization or

individual may not extract or copy part or all of the contents of this manual without any written permission from us, and may not be reproduced and spread in any form (including materials and publications). We have the final right to interpret this manual. This manual is subject to change without prior notice. For more information, please contact support@atesspower.com.

XIII. Annex

13.1 Electrical diagram




Fig11-1. Main circuit diagram

13.2 Contact

Company Name: Shenzhen AteSS Power Technology Co., Ltd

Address: GROWATT-ATESS Industrial Park, No.23 Zhulongtian Road, Shuitian Community, Shiyuan Street, Baoan District, Shenzhen

Website: www.atesspower.com

Service line: +8675529988492

E-mail: info@atesspower.com